


# ElbertonNET



To turn TV on press TV then Power

To turn off both TV and Cable press All Off.

To turn cable on press CBL then Power

Use orange Up and Down arrows to view lineup

To view channel lineup press Guide

Use middle orange button to select highlighted channel

To raise or lower volume use blue Up or Down keys

To change channel use blue Up or Down key

Use numeric key pad to go directly to desired channel